# NoiseMeters

# **Automatic Volume Control - AVC2**

#### Features

- Reduces the volume if turned up too high
- Installs between mixer (or preamp) and amplifiers
- Operation does not disturb club visitors

#### Applications

- Live music in pubs, clubs, hotels and restaurants
- Village halls and social clubs
- Music noise from clubs, pubs and nightclubs
- Public entertainment venues



#### Overview

For pubs, clubs and other entertainment venues with permanent or semipermanently installed music systems.

The AVC2 Automatic Volume Control is a standard 19" rack mounted unit that connects between the mixer (or preamplifier) and the amplifiers. When the average level gets higher than the threshold, it is reduced in discreet steps that should be undetected by anybody listening to the music. This ensures that the enjoyment of visitors to the entertainment venue is not sacrificed. The unit does not reduce the dynamic range of the music, again protecting the enjoyment factor.

Another benefit of the AVC2 is that it **protects the speakers** from the damage that can occur when over-driven.



The Automatic Volume Control is extremely easy to use. It has no external controls, just a display that shows the amount of attenuation that the unit is applying when the threshold has been exceeded.

#### **Frequency Weightings**

Noise measurement and control is usually carried out using the "A" frequency weighting. This is similar to the response of the human ear and is particularly important for noise nuisance and hearing protection applications. However, it is usually the low frequency noise (thumping bass) that can be heard from outside the venue and in nearby properties. It is therefore important to monitor these low frequencies that are effectively removed by the usual "A" weighting.

The Automatic Volume Control can use both "A" weighting and a Linear response. In its default configuration it uses both the "A" weighting and the Linear response, using the higher of the two to check against the threshold. This ensures that the controller will help to protect against both damaging and annoying noise content. It is possible to configure the unit to use either the "A" weighting or the Linear response instead of both.

#### Connection



Connection to the Automatic Volume Control is by XLR connectors for inputs left and right, outputs left and right and for auxiliary connections.

A security cover protects against the connections simply being removed to bypass the volume controller.

#### https://noisemeters.com/p/avc2/

# **NoiseMeters**

### **Automatic Volume Control - AVC2**

## **Specifications**

#### **Technical Specifications**

Technical specifications for the Formula Sound AVC2 Automatic Volume Control.		Threshold Range	High range: Average level adjustable 5dBu -2dBu Low range: Average level
Frequency Response Noise 20Hz to	20Hz - 30kHz ±0.5dB Equiv. input noise < -90dBu	Attenuator Range	adjustable -8dBu -14dBu -3dB -6dB -9dB -12dB -15dB -18dB -24dB -30dB
20kHz Inputs	Electronically balanced, connect negative screen for unbalanced use Input impedance: Balanced 20	Control Chain A control chain with a flat frequency response Linear, "A" weighted, or a combination of both may be selected to control the attenuators.	
	kΩ, Unbalanced 10 kΩ Maximum input level: 22 dBu Clip indicator: Indicates @	Power Finish	110V AC. IEC mains connector. Front and read panels - black
Outputs	20dBu Electronically balanced, connect negative screen for unbalanced use		anodized aluminum with etched silver notation. Case - black plastic-coated steel
	Source impedance: 100 Ω Min load impedance: 600 Ω	Dimensions	19" rack mounting. 1RU Width 482 mm (19"), depth 200 mm (7.9"), height 44 mm (1.75")

#### **Head Office**

NoiseMeters Inc 3233 Coolidge Hwy Berkley MI 48072 USA

Telephone **888 206 4377** Fax **888 584 2230** 

Email: info@noisemeters.com Support: support@noisemeters.com

#### Web Sites

Main site: https://noisemeters.com

Product shortcut: https://noisemeters.com/p/avc2/

Tech Support: https://support.noisemeters.com